

OPERATING INSTRUCTIONS

for
AMPROBE®
MODEL AM-1200
DIGITAL
INDUSTRIAL
MULTIMETER

- See PRECAUTIONS FOR PERSONAL AND INSTRUMENT PROTECTION on page 5.
- See Limited Warranty on page 2



LIMITED WARRANTY

Congratulations! You are now the owner of an AMPROBE® instrument. It has been quality crafted according to quality standards and contains quality components and workmanship. This instrument has been inspected for proper operation of all of its functions. It has been tested by qualified factory technicians according to the long-established standards of AMPROBE INSTRUMENT.

Your AMPROBE instrument has a limited warranty against defective materials and/or workmanship for one year from the date of purchase provided that, in the opinion of the factory, the instrument has not been tampered with or taken apart.

Should your instrument fail due to defective materials, and/or workmanship during the warranty period return it along with a copy of your dated bill of sale which must identify instrument by model number and serial number.

For your protection, please use the instrument as soon as possible. If damaged, or should the need arise to return your instrument, it must be securely wrapped (to prevent damage in transit) and sent prepaid via Air Parcel Post insured or UPS where available to:

Service Division
AMPROBE INSTRUMENT
630 Merrick Road (For U.P.S.)
P.O. Box 329 (For P.P.)
Lynbrook, NY 11563-0329

Outside the U.S.A. the local Amprobe representative will assist you. Above limited warranty covers repair and replacement of instrument only and no other obligation is stated or implied.

2

SPECIFICATIONS

Voltage Ranges

0-1999mV/199.9/750VAC 15KVAC } See Note
0-1.999/19.99/199.9/1000VDC 15KVDC } 1 on
0-1999mV DC } page 4

Resistance Ranges

0-199.9/1999 ohms
0-19.99/199.9/1999K ohms

Current Ranges

0-1999µA DC
0-19.99/199.9/1999mA DC
0-10 Amps DC
0-19.99/199.9/1999mA AC
0-10 amps AC

NOTE: AC Accuracy may be affected by outside interference.

Temperature

-50°F to +250°F. (-45.6°C to +121°C). See Note 2 on page 5

Accuracy

DCV: $\pm 0.5\%$ of rdg ± 2 LSD
ACV: $\pm 1.5\%$ of rdg ± 2 LSD
DC Amps: All ranges $\pm 1.0\%$ of rdg ± 2 LSD except 10 Amp range, which is $\pm 1.5\%$ of rdg ± 3 LSD.
AC Amps: All ranges $\pm 1.5\%$ of rdg ± 2 LSD except 10 Amp range, which is $\pm 2.0\%$ of rdg ± 3 LSD.
Ohms: All ranges $\pm 0.75\%$ of rdg ± 2 LSD except 2 megohm range, which is $\pm 1\%$ of rdg ± 2 LSD.
15 KV AC/DC high voltage probe: add up to $\pm 2\%$ of rdg.

3

Temperature: AM-1200 instrument with RBT-11B/12B/13B probes —

<u>°F Range</u>	<u>°C Equivalent</u>	<u>Accuracy</u>
- 50° to - 31°F	- 45.56° to - 35°C	± 1° F
- 30° to + 5°F	- 34.44° to - 15°C	± 3/2°F
+ 6° to + 100°F	- 14.44° to + 37.78°C	± 1/2°F
+ 101° to + 130°F	+ 38.33° to + 54.44°C	± 3/2°F
+ 131° to + 160°F	+ 55.00° to + 71.11°C	± 1° F
+ 161° to + 212°F	+ 71.67° to + 100°C	± 2° F
+ 213° to + 250°F	+ 100.56° to + 121.11°C	± 3° F

The AM-1200 features auto-zeroing on all ranges.

Power Supply (AM-1200)

Uses one 9V Alkaline Battery (Cat. MN1604).

Circuit Protection

Micro-amp (µA) and milliamp (mA) ranges are fuse protected up to 600 volts AC/DC maximum with a 6.3X25-2-12 two amp fuse. Do not use substitute fuses. See page 16.

All resistance ranges are overload protected against momentary misapplication of up to a maximum of 500V AC/DC for no longer than ten seconds.

The 10 ampere range is overload protected up to 15 amperes maximum. All voltage ranges are overload protected up to 800VAC and 1100VDC.

IMPORTANT: Use of instrument and/or accessories on circuits with higher voltages and/or currents than the indicated overload limits may result in personal injury and/or damage to the instrument and/or accessories.

***Note 1. This range capability is available through the use of an accessory High Voltage Probe Model HV-2 and resistor Model HVR-4. Resistor is not supplied with probe.*

***Note 2. This range capability is available through the use of an accessory temperature probe Model RBT-11B, RBT-12B or RBT-13B† and the Resistance/Temperature Chart on page 11.*

†RBT-13B CANNOT be used in temperatures above 150°F.

**Accessory is not supplied with the basic AM-1200 instrument.

PRECAUTIONS FOR PERSONAL AND INSTRUMENT PROTECTION

- 1) Read these instructions thoroughly and follow them carefully.
- 2) In many instances you will be working with dangerous levels of voltage and/or current; therefore, it is important that you avoid direct contact with any uninsulated, current-carrying surfaces. Appropriate insulating gloves and clothing should be worn.
- 3) Before connecting or disconnecting the meter to or from the circuit to be tested, turn off all power to the circuit.
- 4) Before applying test leads to circuit under test, make certain that leads are plugged into proper jacks and switches are set to proper range and function.
- 5) Before using any electrical instruments or tester for actual testing, the unit should be checked on a low energy high impedance source. **Do not use power distribution lines or any other high energy sources.**

(continued on next page)

- 6) If the instrument should indicate that voltage is not present in circuit, do not touch circuit until you have checked to see that all instrument switches are in proper position and instrument has been checked on a known live line.
- 7) Make certain no voltage is present in circuit before connecting ohmmeter to circuit.

IMPORTANT: Plug in only one accessory probe or set of test leads at any one time, except as directed.

IMPORTANT: Failure to follow these instructions and/or observe the above precautions may result in personal injury and/or damage to the instrument and/or accessories.


GENERAL

To turn the AM-1200 on, slide the on/off switch (fig. 1) to the right until it is in the "on" position, and the digital display appears in the window.


The front panel of the AM-1200 is designed, labeled and color-coded to simplify its operation and to minimize possibility of error.

To activate any particular function and range, move the rotary switch until the mark on the switch knob lines up with desired range in the proper color-coded area.

Figure 1



Low Battery Indication

When "  " appears in the upper left corner of display, replace battery.

Over-range Indication

Over-range (an input which is too large for the selected range) is indicated when "1" without any other number appears in Most Significant Digit position (the first digit on the left of the display). A decimal may or may not appear with the "1" depending on the selected range.

DC/AC Voltage Ranges

All voltage measurements are read directly from the digital display except when using the 15KV AC/DC Probe in which case an appropriate multiplying factor must be applied.

AC VOLTAGE MEASUREMENT (See Operating Precautions on page 5)

- 1) Move rotary switch to desired AC voltage range.
- 2) Plug the Black test lead into the "COM" jack.
- 3) Plug the Red test lead into the "V/Ω" jack.
- 4) Place one test prod on each side of the AC voltage.
- 5) If meter reading falls within the range of a lower scale, move selector switch to the lower range.

For 15KVAC, see Note 1 on page 4 and instructions on page 9.

DC VOLTAGE MEASUREMENT (See Operating Precautions on page 5)

- 1) Move rotary switch to desired DC voltage range.
- 2) Plug the Black test lead into the "COM" jack.
- 3) Plug the Red test lead into the "V/Ω" jack.

- 4) If Negative and Positive sides of the circuit to be tested are known:

a) connect the Black test prod to the Negative side of the circuit.

b) connect the Red test prod to the Positive side of the circuit.

If the Negative and Positive sides of the circuit are not known:

a) connect the Black and Red prods to the circuit.

b) If "-" sign appears in the left of display, reverse the Black and Red probes.

- 5) If meter reading falls within the range of a lower scale, move selector switch to the lower range.

For 15KVDC, see Note 1 on page 4 and instructions on page 9.

HIGH VOLTAGE PROBE 15KV (See Operating Precautions on page 5)

- 1) To use accessory High Voltage Probe Model HV-2 with the AM-1200, unscrew handle from main probe and insert resistor Model HVR-4, (not supplied with probe) with the spring on the resistor toward the handle.
- 2) Screw handle back onto probe.
- 3) Move rotary switch to 200 volts AC or DC.
- 4) Plug instrument's Black Voltage test lead into "COM" jack on AM-1200 and fasten the other end of the lead to "ground" of circuit being tested.
- 5) Plug HV-2 Probe (with resistor installed) into "V/Ω" jack.
- 6) With your hand behind the protective discs on the handle of the probe, touch the probe tip to the circuit under test.

7) Take reading and multiply by 100.

CAUTION: DO NOT EXCEED 15,000 volts AC or DC.

NOTE: Tip of HV-2 Probe is replaceable.

AC/DC CURRENT MEASUREMENTS (See Operating Precautions on page 5)

A milliampere is one thousandth (1/1000) of an ampere and may be written as 1 mA or 0.001 ampere.

A microampere is one millionth (1/1,000,000) of an ampere and may be written as 1 μ A or 0.000001 ampere.

Meter must be connected in series with the circuit under test.

- 1) Using rotary switch, select appropriate function and range. When current is unknown, use the highest current range.
- 2) Plug Black test lead into the "COM" jack.
- 3) Plug Red test lead into the " μ A/mA" jack for measurements up to 200 mA; for readings above 200mA up to 10A, plug Red test lead into "10A" jack.
- 4) Using the Red and Black test leads connect the meter in series with the circuit under test.
- 5) If "-" sign appears to the left of the reading when measuring DC, reverse the Red and Black test leads.
- 6) If meter reading falls within the range of a lower scale, move switch to a lower range.

RESISTANCE MEASUREMENTS (See Operating Precautions on page 5)

- 1) Move rotary switch to desired ohms range.
- 2) Plug the black test lead into the "COM" jack.
- 3) Plug the Red test lead into the "V/ Ω " jack.
- 4) When the test lead tips are shorted together, the display should indicate zero resistance

on all ohmmeter ranges, except for 200 Ω range. This range will indicate resistance of test lead, which is less than 1 Ω .

- 5) Connect test leads across the resistance to be measured. Caution: Resistance to be measured must be disconnected from all power before applying ohmmeter test leads.
- 6) If meter reading falls within the range of a lower scale, reset selector switch to the lower range.

TEMPERATURE

Temperature can be measured using a Model RBT-11B, RBT-12B or RBT-13B* thermistor probe.

*Do not use RBT-13B above 150°F.

- 1) Move rotary switch to appropriate range; see Resistance/Temperature table below.
- 2) Plug the thermistor probe into the "COM" jack and "V/ Ω " jack.
- 3) Insert thermistor probe into medium (non-corrosive) to be measured and allow probe to reach temperature of medium (resistance reading settles).
- 4) Refer to following Resistance/Temperature table for temperature that correlates to resistance reading.

Use 200K range from 55.89 to 20.32K ohms
20K range from 19.60 to 2.04K ohms
2K range from 1.99 to 0.202K ohms
200 ohm range from 197 to 34.7 ohms

AM-1200			AM-1200		
°F	K Ohms	°C	°F	K Ohms	°C
-50	55.89	-45.56	-45	45.98	-42.78
-49	53.71	-45.00	-44	44.52	-42.22
-48	51.66	-44.44	-43	42.58	-41.67
-47	49.68	-43.89	-42	40.95	-41.11
-46	48.85	-43.33	-41	39.45	-40.56

AM-1200		
°F		°C
-40	37.94	-40.00
-39	36.54	-39.44
-38	35.19	-38.89
-37	33.89	-38.33
-36	32.65	-37.78
-35	31.45	-37.22
-34	30.31	-36.67
-33	29.20	-36.11
-32	28.16	-35.56
-31	27.12	-35.00
-30	26.15	-34.44
-29	25.21	-33.89
-28	24.31	-33.33
-27	23.45	-32.78
-26	22.62	-32.22
-25	21.83	-31.67
-24	21.05	-31.11
-23	20.32	-30.56
-22	19.60*	-30.00
-21	18.92	-29.44
-20	18.26	-28.89
-19	17.63	-28.33
-18	17.03	-27.78
-17	16.44	-27.22
-16	15.89	-26.67
-15	15.34	-26.11
-14	14.83	-25.56
-13	14.31	-25.00
-12	13.83	-24.44
-11	13.37	-23.89
-10	12.92	-23.33
-9	12.49	-22.78
-8	12.07	-22.22
-7	11.68	-21.67
-6	11.29	-21.11
-5	10.92	-20.56
-4	10.56	-20.00
-3	10.21	-19.44

*Indicates range change.

AM-1200		
°F	K Ohms	°C
-2	9.88	-18.89
-1	9.56	-18.33
0	9.25	-17.88
1	8.95	-17.22
2	8.67	-16.67
3	8.38	-16.11
4	8.12	-15.56
5	7.85	-15.00
6	7.61	-14.44
7	7.37	-13.89
8	7.14	-13.33
9	6.92	-12.78
10	6.69	-12.22
11	6.49	-11.67
12	6.29	-11.11
13	6.09	-10.56
14	5.90	-10.00
15	5.72	-9.44
16	5.55	-8.89
17	5.38	-8.33
18	5.21	-7.78
19	5.05	-7.22
20	4.90	-6.67
21	4.75	-6.11
22	4.61	-5.56
23	4.47	-5.00
24	4.34	-4.44
25	4.21	-3.89
26	4.08	-3.33
27	3.96	-2.78
28	3.84	-2.22
29	3.73	-1.67
30	3.62	-1.11
31	3.52	-0.56
32	3.41	0
33	3.31	0.56
34	3.22	1.11
35	3.13	1.67

AM-1200		
°F	K Ohms	°C
36	3.04	2.22
37	2.95	2.78
38	2.86	3.33
39	2.78	3.89
40	2.71	4.44
41	2.63	5.00
42	2.55	5.56
43	2.48	6.11
44	2.41	6.67
45	2.35	7.22
46	2.28	7.78
47	2.22	8.33
48	2.16	8.89
49	2.10	9.44
50	2.04	10.00
51	1.99*	10.56
52	1.93	11.11
53	1.88	11.67
54	1.83	12.22
55	1.78	12.78
56	1.73	13.33
57	1.69	13.89
58	1.64	14.44
59	1.60	15.00
60	1.56	15.56
61	1.51	16.11
62	1.47	16.67
63	1.44	17.22
64	1.40	17.78
65	1.36	18.33
66	1.33	18.89
67	1.29	19.44
68	1.26	20.00
69	1.23	20.56
70	1.20	21.11
71	1.17	21.67
72	1.14	22.22
73	1.10	22.78

*Indicates range change.

AM-1200		
°F	K Ohms	°C
74	1.08	23.33
75	1.05	23.89
76	1.03	24.44
77	1.00	25.00
78	0.975	25.56
79	0.951	26.11
80	0.927	26.67
81	0.905	27.22
82	0.882	27.78
83	0.861	28.33
84	0.840	28.89
85	0.820	29.44
86	0.799	30.00
87	0.781	30.55
88	0.762	31.11
89	0.743	31.67
90	0.725	32.22
91	0.708	32.78
92	0.691	33.33
93	0.675	33.89
94	0.659	34.44
95	0.643	35.00
96	0.628	35.56
97	0.614	36.11
98	0.599	36.67
99	0.585	37.22
100	0.572	37.78
101	0.559	38.33
102	0.545	38.89
103	0.533	39.44
104	0.521	40.00
105	0.509	40.55
106	0.497	41.11
107	0.486	41.67
108	0.475	42.22
109	0.464	42.78
110	0.454	43.33
111	0.444	43.89

AM-1200			AM-1200			AM-1200			AM-1200		
°F	K Ohms	°C	°F	Ohms	°C	°F	Ohms	°C	°F	Ohms	°C
112	0.434	44.44	149	197	65.00	187	96.2	86.11	219	55.7	103.89
113	0.424	45.00	150	194	65.56	188	94.5	86.67	220	54.9	104.44
114	0.415	45.56	151	190	66.11	189	92.9	87.22	221	54.0	105.00
115	0.406	46.11	152	186	66.67	190	91.2	87.78	222	53.2	105.56
116	0.397	46.67	153	182	67.22	191	89.7	88.33	223	52.4	106.11
117	0.385	47.22	154	179	67.78	192	88.1	88.89	224	51.6	106.67
118	0.379	47.78	155	175	68.33	193	86.5	89.44	225	50.8	107.22
119	0.371	48.33	156	172	68.89	194	85.0	90.00	226	50.0	107.78
120	0.363	48.89	157	169	69.44	195	83.5	90.56	227	49.2	108.33
121	0.355	49.44	158	165	70.00	196	82.1	91.11	228	48.4	108.89
122	0.347	50.00	159	162	70.56	197	80.7	91.67	229	47.7	109.44
123	0.340	50.56	160	160	71.11	198	79.3	92.22	230	47.0	110.00
124	0.333	51.11	161	156	71.67	199	77.9	92.78	231	46.3	110.56
125	0.325	51.67	162	153	72.22	200	76.6	93.33	232	45.6	111.11
126	0.319	52.22	163	150	72.78	201	75.3	93.89	233	44.9	111.67
127	0.312	52.78	164	147	73.33	202	74.0	94.44	234	44.2	112.22
128	0.305	53.33	165	144	73.89	203	72.8	95.00	235	43.5	112.78
129	0.299	53.89	166	142	74.44	204	71.5	95.56	236	42.8	113.33
130	0.292	54.44	167	139	75.00	205	70.4	96.11	237	42.2	113.89
131	0.286	55.00	168	136	75.56	206	69.2	96.67	238	41.6	114.44
132	0.280	55.55	169	134	76.11	207	68.0	97.22	239	41.0	115.00
133	0.274	56.11	170	131	76.67	208	66.9	97.78	240	40.8	115.56
134	0.269	56.67	171	129	77.22	209	65.8	98.33	241	39.7	116.11
135	0.263	57.22	172	127	77.78	210	64.7	98.89	242	39.1	116.67
136	0.258	57.78	173	124	78.33	211	63.6	99.44	243	38.6	117.22
137	0.252	58.33	174	122	78.89	212	62.5	100.00	244	38.0	117.78
138	0.247	58.89	175	120	79.44	213	61.5	100.56	245	37.4	118.33
139	0.242	59.44	176	117	80.00	214	60.9	101.11	246	36.9	118.89
140	0.237	60.00	177	115	80.55	215	59.5	101.67	247	36.4	119.44
141	0.232	60.56	178	113	81.11	216	58.5	102.22	248	35.8	120.00
142	0.228	61.11	179	111	81.67	217	57.6	102.78	249	35.3	120.56
143	0.223	61.67	180	109	82.22	218	56.7	103.33	250	34.7	121.11
144	0.218	62.22	181	107	82.78						
145	0.214	62.78	182	105	83.33						
146	0.210	63.33	183	103	83.89						
147	0.206	63.89	184	102	84.44						
148	0.202	64.44	185	100	85.00						
			186	98.0	85.56						

FUSE AND BATTERY REPLACEMENT

The fuse that protects the μA and mA ranges of the instrument is a 2 Amp, 600V AC/DC fuse. (Cat. No. 6.3x25-2-12)

- 1) If the fuse is blown or battery has to be replaced, remove a single screw on bottom of back cover. Lift off back cover.
- 2) Replace fuse or battery as needed. Do not use a substitute fuse.
- 3) Replace cover and tighten screw.

WARRANTY

Serial number is located on the label on the back of the instrument.

For Factory service, package instrument and packing slip with sufficient cushioning material in a shipping carton; make certain your name and address also appear on box as well as packing slip; ship prepaid via U.P.S. (where available) or Air Parcel Post insured to:

Service Division
AMPROBE INSTRUMENT
630 Merrick Road (Use for U.P.S.)
P.O. Box 329 (Use for Parcel Post)
Lynbrook, NY 11563-0329

Outside the U.S.A. the local Amprobe representative will assist you.

Printed in Taiwan